




Xerox® C240




www.xerox.com/C240EasyAssistApp




www.xerox.com/C240EasyAssistApp




1




2




3




4




5




6




7




8



9



10



11

