




Xerox® C300




www.xerox.com/C300EasyAssistApp




www.xerox.com/C300EasyAssistApp




1




2




3




4




5




6




7




8



9



10



11

