




10




11




12




13






14




15




Xerox® M5300 Series







1




2




3




4




5



e



7



8

