




9




10




11




12






13



14






Xerox® MX830 Series







[www.xerox.com/
CC2026EasyAssistApp](http://www.xerox.com/CC2026EasyAssistApp)


1




2




3




4




5



6



7



8

