




10





11



12



# Xerox® XC2432



[www.xerox.com/XC2432EasyAssistApp](http://www.xerox.com/XC2432EasyAssistApp)



[www.xerox.com/XC2432EasyAssistApp](http://www.xerox.com/XC2432EasyAssistApp)



