




9




10




11




12






13



14






Xerox® XM7400 Series







www.xerox.com/CC2026EasyAssistApp


1




2




3




4





5



6



7



8

